

ASSEMBLY INSTRUCTION

Item No : GW-TA-2426-RBC-C

GW-TA-2426-RWC-C

Description : END TABLE



IMPORTANT NOTE :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws / bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

COMPONENT LIST

| NO | DESCRIPTION | QTY/PCS |
|----|-------------|---------|
| 1 | TABLE TOP | 1 PC |
| 2 | TABLE LEG | 4 PCS |
| 3 | SHELF | 1 PC |

HARDWARE LIST

| NO | DESCRIPTION | QTY/PCS |
|----|------------------------|---------|
| A | JCBB SCREW M8 x 70 | 12 PCS |
| B | SPRING WASHER 5/16" | 12 PCS |
| C | FLAT WASHER 5/16" x 22 | 12 PCS |
| D | ALLEN KEY M5 | 1 PC |

